


FERROX

safety igniter

Ignites, immediately,
burning lances and
oxygen tubes **ONLY**
through the flow of oxygen!




1.




-  Blås ur lansen.
-  Blow through the lance.
-  Lanze ausblasen.
-  Souffler pour vider l'air de la lance.
-  Puhalla putki puhtaaksi.
-  ПРОДУЙТЕ ТРУБУ
-  랜스에 공기를 불어 넣는다
-  ランスで酸素を吹き込みます。

2.



-  Tryck fast brännitändaren.
-  Attach the igniter.
-  Brennerzünder festdrücken.
-  Mettre l'allumeur en place par pression.
-  Paina sytytin kiinni.
-  НАСАДИТЕ ВОСПЛАМЕНИТЕЛЬ
-  스파크를 고정시킨다
-  燃焼点火器をしっかり取りつけます。

3.



-  Håll lansen mot ett stopp och dra på oxygen.
-  Hold the lance against a hard surface turn on the oxygen supply.
-  Lanze gegen ein Widerlager drücken und Sauerstoff öffnen
-  Appuyer la lance contre une surface dure et ouvrir l'arrivée d'oxygène.
-  Paina putki rajoitinta vasten ja avaan hapensyöttö.
-  ПРИЖМИТЕ ТРУБУ К УПОРУ И ОТКРОЙТЕ ПОДАЧУ КИСЛОРОДА
-  스톱에 랜스를 댄 후 산소를 뿜는다
-  ランスを底に向けて酸素を吹きかけます。

FERROX

SE-712 82 GRYTHYTAN • Tel +46 591-143 55 • Fax +46 591-142 64 • www.ferrox.com

